



100 MOST POPULAR KEYWAYS

The following is a list of the 100 most popular ILCO keyways, listed in EZ number sequence.

These keys may be available in several styles and finishes/materials not listed here (plastic head, Look Alike®, brass, nickel silver).

EZ Number	Ilco Number	Fits	EZ Number	Ilco Number	Fits
AM3	1045	American Lock	DA34	X237	Nissan (formerly Datsun)
AP1	101AM	A.P.S. (Chicago)	DC3	X121	Several Automotive
AP2	102AM	A.P.S. (Chicago)	DE6	D1054K	Dexter (also Master)
AP3	103AM	A.P.S. (Chicago)	EZ1	1522	Imported Residential locks
AP4	104AM	A.P.S. (Chicago)	FA3	A1054WD	Falcon
AR1	1179	Arrow	FR2	L1054G	Fort
AR4	1179A	Arrow	H50	S1167FD	Ford
B1	1098M	Briggs & Stratton	H51	1167FD	Ford
B44	P1098E	General Motors	H54	1184FD	Ford
B45	S1098H	General Motors	H60	1190LN	Ford
B48	P1098A	General Motors	H67	1193FD	Ford
B49	S1098B	General Motors	H75	1196FD	Ford
B50	P1098C	General Motors	H76	X244	Ford
B51	S1098D	General Motors	HD90	X181	Honda
B52	1098GX	General Motors	HD91	X182	Honda
B65	X184	GM / Isuzu / Honda	HD103	X214	Honda
B77	P1098EV	General Motors	HR2	TE3	Harloc
B86	P1106	General Motors	IL11	1043J	Illinois
B89	P1107	General Motors	IN3	X1054K	Ilco
B92	P1109	General Motors	IN8	L1054B	Ilco
BE2	A1114A	Best	IN29	1054UN	Ilco
CG1	1041G	Chicago	IN33	1054MT	Ilco
CG16	1041T	Chicago	IN35	1054DL	Ilco
CO68	S1000V	CCL (Corbin Cabinet Lock)	KW1	1176	Kwikset
CO88	A1001EH	Corbin	KW10	A1176ST	Kwikset / Titan
CO106	1003M	Corbin	M1	1092	Master Master/Dexter
DA25	X123	Nissan (formerly Datsun)			

EZ Number	Ilco Number	Fits	EZ Number	Ilco Number	Fits
M2	1092B	Master Master/Dexter	SE1	1022	Segal
M10	1092N	Master Master/Dexter	TR33	X137	Toyota
M12	1092D	Master Master/Dexter	TR37	X159	Toyota
M13	1092DS	Master Master/Dexter	TR39	X151	Toyota
M16	1092NR	Master Master/Dexter	TR40	X174	Toyota
MD17	MD1054K	Master / Dexter	TR47	X217	Toyota
MIT1	X176	Mitsubishi	VR7	VR91AR	Viro
MZ13	X131	Mazda	WK2	1175N	Weslock
MZ27	X222	Mazda	WR3	1054WB	Weiser
NA12	1069LB	(NCL) National Cabinet Lock	WR5	N1054WB	Weiser
NA14	1069L	(NCL) National Cabinet Lock	Y1	999	Yale
RA4	1970AM	Several Automotive	Y2	999A	Yale
RO1	1069	(NCL) National Cabinet Lock	Y6	997X	Yale
RO3	1069N	(NCL) National Cabinet Lock	Y11	O1122	Yale
RO7	1069G	(NCL) National Cabinet Lock	Y12	O1122A	Yale
RU101	A1011-L4	Russwin (Corbin / Russwin)	Y13	O1122R	Yale
RU46	A1011D1	Russwin (Corbin / Russwin)	Y52	997E	Yale
S22	O1007LA	Sargent	Y78	998GA	Yale
SC1	1145	Schlage	Y153	P1786	Chrysler
SC4	1145A	Schlage	Y154	P1789	Chrysler
SC20	A1145L	Schlage	Y155	P1793	Chrysler
			Y157	P1794	Chrysler
			Y159	P1795	Chrysler
			62DT	X6	Nissan (formerly Datsun)
				1028	Safe Deposit
				1137B	Tubular